



spare parts list for AG0821

NO.	part name	Chinese name	specification	Q'ty	material	price
1	outer flange	外压板		1	45#	
2	grinding wheel	砂轮片	125	1		
3	inner flange	内压板		1	粉末冶金	
4	key	半圆键	4*5*13	1		
5	output shaft	输出轴		1	40CR	
6	dust cap	防尘盖		1	Q235	
7	wheel guard	砂轮罩		1	Q235	
8	screw	十字槽盘头螺钉	M5*15	1		
9	o-ring	O型橡胶圈	$\Phi 8*\Phi 4*\Phi 2$	1		
10	screw	十字槽盘头螺钉	M4*12	4		
11	front cover	前盖		1	ADC12	
12	bearing	深沟球轴承	6201RS	1		
13	retaining ring	孔用弹性挡圈	$\Phi 32$	1		
14	gear	大齿轮		1	42CRMO	
15	retaining ring	轴用弹性挡圈	$\Phi 12$	1		
16	bearing	深沟球轴承	6201RS	1		
17	rubber column	橡胶柱		1		
18	screw	十字槽盘头自攻螺钉	ST4*25	4		
19	pin	自锁销		1	45#	
20	o-ring	O型橡胶圈	$\Phi 6*\Phi 4*\Phi 1$	1		
21	spring	自锁弹簧		1	65MN	
22	cap	自锁帽		1	PA6-GF30	
23	gear box	头壳		1	ADC12	
24	nut	防松螺母	M6	1		
25	small gear	小齿轮		1	42CRMO	
26	bearing	深沟球轴承	629RS	1		
27	o-ring	O型橡胶圈	$\Phi 30*\Phi 26*\Phi 2$	1		
28		中间盖		1	ADC12	
29	rotor	转子		1		
30	Creepage	档圈		1	PA6-GF30	
31	bearing	深沟球轴承	607Z	1		
32	rubber	轴承套		1	橡胶	
33	screw	十字槽盘头自攻螺钉	ST4*80	2		
34	wind scooper	导风圈		1	PA6-GF30	
35	stator	定子		1		
36	housing	机壳		1	PA6-GF30	
37	carbon brush	碳刷		2		
38	brush holder	碳刷架		2	H62	
39	screw	十字槽盘头自攻螺钉	ST3*8	4		
40	spring	盘簧		2		

41	capacitor	电容		1		
42	switch	开关		1		
43	cable clamp	电缆压板		1	PA6-GF30	
44	screw	十字槽盘头自攻螺钉	ST4*14	2		
45	end cap	后罩		1	PA6-GF30	
46	screw	十字槽盘头自攻螺钉	ST4*16	1		
47	nameplate	标贴铭牌		1		
48	switch button	开关推钮		1	PA6-GF30	
49	nameplate	型号铭牌		1		
50	switch drawbar	开关拉杆		1	PA6-GF30	
51	spring	拉杆弹簧			65MN	
52	cable sleeve	电缆护套		1		
53	cable	电缆线		1		
54	spanner	扳手			Q235	