

RODEE® spare parts list for CL1800

No.	English Name	Chinese Name	specification	Q'ty	material	price
1	screw	螺钉	M5*22 left	1		
2	chuck	夹头	Φ0.8-Φ10	1		
3	c-ring	挡圈	Φ20.4	1		
4	posmon plate for clutch cap		THK=0.8	1	65Mn	
5	clutch cap			1	PA66+GF30	
6	torque control spring			2	65Mn	
7	sleeve			1	PA66+GF30	
8	torque control spring			1	65Mn	
9	washer for torque			1	65Mn	
10	pin		Φ4*6	6	GCr15	
11	sleeve shaft		SΦ4	6	GCr15	
12	output shaft			1		
13	bearing		689Z	1		
14	gear box housing			1	PA66+GF30	
15	carrier spring			1		
16	rivet			1		
17	carriet clutch cap			1		
18	carriet			1	ABS	
19	axle spring			1		
20	shaft lock ring			1		
21	shaft lock pin		Φ3.02*4.8	6	GCr15	
22	shaft locking block			1	SMF5040	
23	the 3th ring gear			1	SMF5040	
24	shaft lock planet carrier			1	SMF5040	
25	the 3nd planet gear			5	SMF5040	
26	flat washer			1		
27	gear box pin		Φ2.5*29	2	GCr15	
28	gear box sleeve			1		
29	the 2nd planet garrier			1		
30	the 2nd planet gear			5		
31	movable gear			1		
32	the 1th planet carrier			1		
33	the 1th ring gear			1		
34	the 1th planer gear			3		
35	planet washer			1		
36	ST screw		M3*8	2		
37	motor mounting			1		
38	motor gear			1		
39	motor		18V-550	1		
40	housing			1		
41	led lamp red line		L=145	1		
42	F-R lever			1		
43	switch			1		
44	contact plat asseby			1		
45	hand sling			1		
46	housing			1		
47	ST screw		ST2.9*11.5	10		

48	battery		18V	1		
49	battery label 1			1		
50	battery label 2			1		
51	battery label 3			1		
52	housing label 1			1		
53	housing label 2			1		