



Spare part list for D0800

No	Part name	Chinese name	Specification	Q'ty	Material	price
1	Screw	钻夹头螺钉	M6×25-L	1		
2	Chuck	钻夹头	16MM	1		
40	Chuck key	夹头钥匙		1		
3	Circlip for shaft	孔用弹性挡圈	φ35	2		
4	Washer 1	挡油垫片		2		
5	Seal loop	羊毛油封	φ32×φ16×4	1		
6	Output shaft	输出轴		1		
7	Ball Bearing	深沟球轴承	6003-2Z	1		
8	Screw	自攻螺钉	ST4.8×35	4		
9	Washer 2	平垫圈5		4		
10	Gear box	头壳		1		
11	Locating sleeve	定位套	φ21.5×φ17.5×8	1		
12	Gear 1	大齿轮		1		
13	Semicircle key	半圆键	4×13	1		
14	Circlip for shaft	轴用弹性挡圈	φ14	1		
15	Needle bearing	滚针轴承	HK0810	1		
16	Middle cover	中间盖		1		
17	Ball Bearing	深沟球轴承	607-2Z	1		
18	Middle shaft	中间轴		1		
19	Steel ball	钢球5φ4		1		
20	Gear 2	斜齿轮		1		
21	Washer 3	平垫圈	φ13×φ7×0.8	2		
22	Needle bearing	滚针轴承	HK0709	1		
23	Spin	圆柱销4×10		1		
24	Ball Bearing	深沟球轴承	629-2RZ	1		
25	Washer 4	平垫圈	φ18×φ10×0.5	1		
26	Rotor	电枢总成	φ41.3×40	1		
27	Fan shroud	挡风圈		1		
28	Screw	自攻螺钉	ST4.2×55	2		
29	Stator	定子总成	φ72×40	1		
30	Creepage retainer ring	爬电挡圈		1		

31	Ball Bearing	深沟球轴承	608-2Z	1		
32	Bearing sheath	轴承衬套		1		
33	Housing	机壳		1		
34	Handle cover	手柄盖		1		
35	Side handle	侧手柄		1		
36	Carbon brush cap	刷握盖		2		
38	Brush holder	刷握		2		
37	Carbon brush	碳刷		2		
39	Spring	拉簧		2		
45	Lef handle	左手柄		1		
52	Right handle	右手柄		1		
43	Rear handle(right)	右后手柄		1		
42	Rear handle(left)	左后手柄		1		
46	Screw	自攻螺钉	ST4.2×14	2		
47	Cable	电缆线	H05VV-F/2×0.75 ²	1		
48	Cable sleeve	电缆护套		1		
49	clip	电缆压板		1		
50	Connector	接线座		1		
51	Screw	自攻螺钉	ST4.8×25	4		
53	Switch	开关	TN36 10(10A)250V~5E4	1		
44	Screw	自攻螺钉	ST4.2×18	7		
41	Trade mark lable	商标		1		
54	Name plate	铭牌		1		